

How we measure

Shown on Junus and Killian sofa beds



Measure guide introduction

We've made a guide to showcase the methods behind how Innovation Living measure heights, depths and lengths on the collection.

We use the following tools to get the most correct measurements:

- 1 Spirit level
- 1 Measuring tape

Note: We've used packshot pictures to get as close to the reality as possible in terms of showing the way of measuring correctly. The shown pictures in the measuring guide may vary in expression compared to the sofa you're in possession of.



Sofa Depth

The sofa depth is measured from the front of the sofa to the back of the sofa.


The sofa depth is measured in sofa position. Some models has the possibility to lower the back position to various relaxed positions. This will increase the sofa depth.



Bed Width

The bed width is measured from the front of the sofa to the back of the sofa.


The bed width is measured in bed position.



Sofa Height

The sofa height is measured from the lowest point of the sofa to the highest point of the sofa.

The sofa height is measured in sofa position.



Sofa Width

The sofa width is measured from the furthest point to the right of the sofa to the furthest point to the left of the sofa.

The sofa width is measured in sofa position.




Seat Depth

The seat depth is measured from the front seat to the back seat.

The seat depth is measured in sofa position.

Please notice that we always measure the seat depth alongside the seat to the lower part of the back.



Seat Height

The seat height is measured from the ground to the top of the mattress.

The seat height is measured in sofa position.

Please notice that we always measure the seat height from the middle of the sofa bed.



Arm Height

The arm height is measured from the lowest point of the arm to the highest point of the arm.

The arm height is measured in sofa position.




Mattress Height

The mattress height is measured from the bottom of the mattress to the top of the mattress.

The mattress height is measured in sofa position.


Please notice that we always measure the mattress height from the middle of the mattress.



Bed Length

The bed length is measured from the left side of the mattress to the right side of the mattress.

The bed length is measured in sofa position.



Bed Width

The bed width is measured from the left side of the mattress, to the right side of the mattress.

The bed width is measured in bed position.


Please notice this way of measuring the bed width includes: Killian, Vithus & Eivor



Bed Height - with bed inside

The bed height is measured from the floor to the top of the mattress.

The bed height is measured in bed position.






Bed Length - with bed inside

The bed length is measured from the inner part of the back frame to the inner part of the front frame.


The bed length is measured in bed position.

Please notice this way of measuring the bed length includes: Killian, Vithus & Eivor




Sofa bed gap from floor to base


Make sure to measure the gap between the floor and the frame of the sofa bed at the lowest point.



Width



Depth




Height



Width



Depth




Height



Width



Depth



Height

Sofa bed cushions

Make sure to measure the cushions at their widest, deepest and highest spot as shown in the examples below